

FRENIC-Mini
FRENIC-Eco
FRENIC-Multi

User's Manual
for RS-485 Communications Card

Copyright © 2003-2007 Fuji Electric FA Components & Systems Co., Ltd.
All rights reserved.

The copyright in this user's manual belongs to Fuji Electric FA Components & Systems Co., Ltd.
This manual may not be reprinted or reproduced, in whole or in part, except as may be expressly permitted by
Fuji Electric FA Components & Systems Co., Ltd.

Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation, U.S. The other
company and product names used herein are generally trademarks or registered trademarks of other
companies.

Any information contained herein is subject to change without prior notice for improvement.

Preface

The functions such as remote operation from the keypad and RS-485 communications can be expanded using the RJ-45 connector for connecting the keypad (modular jack) and RS-485 communications card (option) equipped on the inverter. This manual describes the functional expansion. For the handling of the inverter, see each User's Manual and Instruction Manual.

Please read through this user's manual to familiarize yourself with proper use. Improper handling or misuse may result in malfunction, shorter service life or failure.

This user's manual describes RS-485 communications function commonly used for FRENIC-Mini, FRENIC-Eco, and FRENIC-Multi (FRENIC series).

The following shows relevant documents. Use the documents according to your purpose.

FRENIC-Mini

Name	Description
User's Manual	Overview of FRENIC-Mini, how to operate the keypad, control block diagram, selection of peripherals, capacity selection, specifications, function codes, etc.
Catalog	Overview of FRENIC-Mini, features, specifications, outline drawing, options, etc.
Instruction Manual	Inspection at the time of product arrival, installation and wiring, how to operate the keypad, troubleshooting, maintenance and inspection, specifications, etc.
RS-485 communications card Installation Manual	Inspection at the time of arrival, how to install the product

FRENIC-Eco

Name	Description
User's Manual	Overview of FRENIC-Eco, how to operate the keypad, control block diagram, selection of peripherals, capacity selection, specifications, function codes, etc.
Catalog	Overview of FRENIC-Eco, features, specifications, outline drawing, options, etc.
Instruction Manual	Inspection at the time of product arrival, installation and wiring, how to operate the keypad, troubleshooting, maintenance and inspection, specifications, etc.
RS-485 communications card Installation Manual	Inspection at the time of arrival, how to install the product

FRENIC-Multi



Name	Description
User's Manual	Overview of FRENIC-Multi, how to operate the keypad, control block diagram, selection of peripherals, capacity selection, specifications, function codes, etc.
Catalog	Overview of FRENIC-Multi, features, specifications, outline drawing, options, etc.
Instruction Manual	Inspection at the time of product arrival, installation and wiring, how to operate the keypad, troubleshooting, maintenance and inspection, specifications, etc.
RS-485 communications card Installation Manual	Inspection at the time of arrival, how to install the product

These documents are subject to revision as appropriate. Obtain the latest versions when using the product.


■ Safety Precautions

Prior to installation, connection (wiring), operation, maintenance or inspection, read through this user's manual as well as the instruction and installation manuals to ensure proper operation of the product. Familiarize yourself with all information required for proper use, including knowledge relating to the product, safety information, and precautions.


This user's manual classifies safety precautions as shown below according to the severity of the accident that may occur if you fail to observe the precaution:


 WARNING	Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in death or serious bodily injuries.
 CAUTION	Failure to heed the information indicated by this symbol may lead to dangerous conditions, possibly resulting in minor or light bodily injuries and/or substantial property damage.

Failure to heed the information contained under the CAUTION title can also result in serious consequences. These safety precautions are of utmost importance and must be observed at all times.

 CAUTION
<p>The FRENIC-Mini/Eco is not designed for use in appliances and machinery on which lives depend. Consult Fuji before considering the FRENIC-Mini/Eco series of inverters for equipment and machinery related to nuclear power control, aerospace uses, medical uses or transportation. When the product is to be used with any machinery or equipment on which lives depend or with machinery or equipment which could cause serious loss or damage should this product malfunction or fail, ensure that appropriate safety devices and/or equipment are installed.</p>

Wiring

 WARNING
<ul style="list-style-type: none"> - Before starting wiring, confirm that the power is turned OFF (open). An electric shock may result.

 CAUTION
<ul style="list-style-type: none"> - The product cannot be connected directly to an RS-232C interface. - Before connecting wiring to the RJ-45 connector (modular jack) for connecting the keypad, equipped on the inverter (FRENIC-Eco) or the RJ-45 connector (modular jack) on the RS-485 communications card (option) (FRENIC-Mini), confirm the wiring of the device to be connected. For further information, see "2.2 Connections" under Chapter 2 of this manual. Failure may result.

Operation


 WARNING
<ul style="list-style-type: none"> - Note that the inverter starts to supply power to the motor and the motor runs upon resetting of an alarm with the operation command ON (closed). An accident may result.

Table of Contents

CHAPTER 1 OVERVIEW

1.1	Features	1-1
1.2	List of Functions	1-2

CHAPTER 2 COMMON SPECIFICATIONS

2.1	Specifications of RS-485 Communications	2-1
2.1.1	Specification of the RJ-45 connector for RS-485 communications (modular jack)	2-3
2.1.2	Specification of the terminal for RS-485 communications	2-4
2.1.3	RJ-45 connector (modular jack) for function expansion	2-4
2.1.4	Specification of connection cable for RS-485 terminal	2-6
2.2	Connections	2-7
2.2.1	Basic connection	2-7
2.2.2	Connection procedures	2-10
2.2.3	Devices for connection	2-14
2.2.4	Measures against noise	2-15
2.3	Switching to Communications	2-17
2.3.1	Functions for the switching	2-17
2.3.2	Link functions (operation selection)	2-18
2.3.3	How to switch communications enabled/disabled	2-19
2.3.4	Link functions for supporting data input (operation select)	2-20
2.4	Making RS-485-related Settings	2-21
2.4.1	Link function (RS-485 setting)	2-21

CHAPTER 3 Modbus RTU PROTOCOL

3.1	Messages	3-1
3.1.1	Message formats	3-1
3.1.2	Message types	3-1
3.1.3	Message frames	3-2
3.1.4	Message categories	3-4
3.1.5	Communications examples	3-11
3.2	Host Side Procedures	3-12
3.2.1	Inverter's response time	3-12
3.2.2	Timeout processing	3-13
3.2.3	Receiving preparation complete time and message timing from the host	3-14
3.2.4	Frame synchronization method	3-14
3.3	Communications Errors	3-15
3.3.1	Categories of communications errors	3-15
3.3.2	Operations in case of errors	3-16
3.4	CRC-16	3-19
3.4.1	Overview of the CRC-16	3-19
3.4.2	Algorithm	3-19
3.4.3	Calculation example	3-21
3.4.4	Frame length calculation	3-22

CHAPTER 4 FUJI GENERAL-PURPOSE INVERTER PROTOCOL

4.1	Messages	4-1
4.1.1	Message formats	4-1
4.1.2	Transmission frames	4-2
4.1.3	Descriptions of fields.....	4-10
4.1.4	Communications examples.....	4-12
4.2	Host Side Procedures	4-14
4.2.1	Inverter's response time	4-14
4.2.2	Timeout processing.....	4-15
4.2.3	Receiving preparation complete time and message timing from the host.....	4-15
4.3	Communications Errors.....	4-16
4.3.1	Categories of communications errors.....	4-16
4.3.2	Operations in case of communications errors	4-17

CHAPTER 5 FUNCTION CODES AND DATA FORMATS

5.1	Communications Dedicated Function Codes	5-1
5.1.1	About communications dedicated function codes	5-1
5.1.2	Command data	5-2
5.1.3	Monitor data.....	5-8
5.1.4	Information displayed on the keypad.....	5-12
5.2	Data Formats.....	5-21
5.2.1	List of data format numbers.....	5-21
5.2.2	Data format specifications	5-36