

## AH-series Pushbutton cross to AR-series Pushbutton

PART #	PART #	PART #	PART #	TYPE
AH22-AA@.....@	AR22A5N-@@@@B	AH30-SAA@.....@	AR30A5N-@@@@B	Wobble stick switch
-	AR22A5H-@@@@B	AH30-SAA@.....@-S	AR30A5H-@@@@B	
AH22-ALA@.....@	AR22A6N-@@@@B	AH30-SALA@.....@	AR30A6N-@@@@B	
-	AR22A6H-@@@@B	AH30-SALA@.....@-S	AR30A6H-@@@@B	
AH22-ALM@.....@	AR22A1N-@@@@B	AH30-SALM@.....@	AR30A1N-@@@@B	
AH22-AM@.....@	AR22A0N-@@@@B	AH30-SAM@.....@	AR30A0N-@@@@B	
-	AR22A0H-@@@@B	AH30-SAM@.....@-S	AR30A0H-@@@@B	
-	AR22A1H-@@@@B	AH30-SALM@.....@-S	AR30A1H-@@@@B	
-	AR22A2N-@@@@B	-	AR30A2N-@@@@B	
-	AR22A2H-@@@@B	-	AR30A2H-@@@@B	
-	AR22A7N-@@@@B	-	AR30A7N-@@@@B	
-	AR22A7H-@@@@B	-	AR30A7H-@@@@B	
-	-	AH30-B1#@@	AR30B0R-@@#	
-	-	AH30-B2#@@	AR30B1R-@@#	
-	-	AH30-B3#@@	AR30B2R-@@#	
-	-	AH30-B4#@@	AR30B3R-@@#	
-	-	AH30-C@@%	-	Coin
-	-	AH30-D@@%	-	Key
AH22/25-E#@@	AR22E0R-@@#	AH30-E#@@	AR30E0R-@@#	Round extended head
AH22/25-E5#@@	AR22E5R-@@#	AH30-E5#@@	AR30E5R-@@#	
AH22-EL#@*#&	AR22E0L-@@*#&	-	-	
AH22-EL5#@*#&	AR22E5L-@@*#&	-	-	E-stop
-	-	AH30F#@@/ES	AR30FVR-@@#	
AH22/25-F#@@	AR22F0R-@@#	AH30-F#@@	AR30F0R-@@#	Flush head
AH22/25-F5#@@	AR22F5R-@@#	AH30-F5#@@	AR30F5R-@@#	
AH25-G#@@	AR22G0R-@@#	AH30-G#@@	AR30G0R-@@#	w/guard
AH22/25-G1#@@	AR22G3R-@@#	AH30-G1#@@	AR30G1R-@@#	
-	-	AH30-G3#@@	AR30GPR-@@#	Pin-lock
AH25-G5#@@	-	AH30-G5#@@	-	w/guard
AH22/25-G6#@@	AR22G8R-@@#	AH30-G6#@@	AR30G6R-@@#	
AH22-GL1#@*#&	AR22G4L-@@*#&	-	-	w/guard
AH22-GL6#@*#&	AR22G9L-@@*#&	-	-	
-	-	AH30-H2@@	AR30WR-2@@#	Selector switch
-	-	AH30-H3@@	AR30WR-3@@#	
AH22/25-J0A@@%	AR22JR-0A@@%	AH30-J0A@@%	AR30JR-0A@@%	Key selector switch
AH22/25-J1E@@%	AR22JR-1E@@%	AH30-J1E@@%	AR30JR-1E@@%	
AH22/25-J2\$@@%	AR22JR-2\$@@%	AH30-J2\$@@%	AR30JR-2\$@@%	
AH22/25-J3\$@@%	AR22JR-3\$@@%	AH30-J3\$@@%	AR30JR-3\$@@%	
AH22/25-J6\$@@%	AR22JR-6\$@@%	AH30-J6\$@@%	AR30JR-6\$@@%	
AH22/25-J7\$@@%	AR22JR-7\$@@%	AH30-J7\$@@%	AR30JR-7\$@@%	
AH22-JC1E@@@%	AR22JCR-1\$@@@%	AH30-JC\$@@@%	AR30JCR-3\$@@@%	
AH22-JC3\$@@@%	AR22JCR-3\$@@@%	-	-	
AH22-JC6\$@@@%	AR22JCR-6\$@@@%	-	-	
AH22-JC7\$@@@%	AR22JCR-7\$@@@%	-	-	
-	-	AH30-K2\$@@	-	
-	-	AH30-K3\$@@	-	

@: contacts arrangement  
#: color of button or grove  
\*: lamp voltage

&: lamp type  
\$: draw-out position of key  
%: type of key

PART #	PART #	PART #	PART #	TYPE
AH25-L#@*%&	AR22E0L-@@*%&#	AH30-L#@*%&	AR30E0L-@@*%&#	Extended
AH25-L2#@*%&	AR22G4L-@@*%&#	AH30-L2#@*%&	AR30G4L-@@*%&#	w/guard
AH25-L3#@*%&	AR22G4L-@@*%&#	AH30-L3#@*%&	AR30G3L-@@*%&#	
AH25-L4#@*%&	AR22G4L-@@*%&#	AH30-L4#@*%&	AR30G4L-@@*%&#	
AH25-L5#@*%&	AR22E5L-@@*%&#	AH30-L5#@*%&	AR30E5L-@@*%&#	
AH25-L6#@*%&	AR22G9L-@@*%&#	AH30-L6#@*%&	AR30G9L-@@*%&#	w/guard
AH25-L7#@*%&	AR22G9L-@@*%&#	AH30-L7#@*%&	AR30G8L-@@*%&#	
AH22-M#@@	AR22M0R-@@#	AH30-M#@@	AR30M0R-@@#	Mushroom head
AH25-M#@@	AR22M4R-@@#	-	-	
-	-	AH30-M2#@@	-	
AH22-M2#@@	AR22M3R-@@#	AH30-M1#@@	AR30M3R-@@#	
AH22-M5#@@	AR22M5R-@@#	AH30-M5#@@	AR30M5R-@@#	
AH25-M5#@@	AR22M5R-@@#	-	-	
-	-	AH30-M6#@@	-	
AH22-M7#@@	-	AH30-M7#@@	-	
AH22-ML#@*%&	AR22M0L-@@*%&#	-	-	
AH22-ML5#@*%&	AR22M5L-@@*%&#	-	-	
AH22-MS#@@	AR22M4R-@@#	AH30-MS#@@	AR30M4R-@@#	
AH22-MS5#@@	-	AH30-MS5#@@	-	
AH22-MSL#@*%&	AR22M4L-@@*%&#	-	-	
AH22-MSL5#@*%&	-	-	-	
-	-	AH30-NR@@	AR30N0R-@@R	Turn-lock
AH22/25-P0#@@	AR22PR-0@@#	AH30-P0#@@	AR30PR-0@@#	Selector switch
AH22/25-P1#@@	AR22PR-1@@#	AH30-P1#@@	AR30PR-1@@#	
AH22/25-P2#@@	AR22PR-2@@#	AH30-P2#@@	AR30PR-2@@#	
AH22/25-P3#@@	AR22PR-3@@#	AH30-P3#@@	AR30PR-3@@#	
AH25-P5#@@	AR22PR-6@@#	-	-	
AH22-P6#@@	AR22PR-6@@#	AH30-P5#@@	AR30PR-6@@#	
AH22-P7#@@	AR22PR-7@@#	AH30-P6#@@	AR30PR-7@@#	
AH25-PC#@@	AR22PCR-3@@@#	AH30-PC#@@	AR30PCR-3@@@#	
AH22-PC1#@@@	AR22PCR-1@@@#	-	-	
AH22-PC3#@@@	AR22PCR-3@@@#	-	-	
AH22-PC4#@@@	AR22PCR-4@@@#	-	-	
AH22-PC5#@@@	AR22PCR-5@@@#	-	-	
AH22-PC6#@@@	AR22PCR-6@@@#	-	-	
AH22-PC7#@@@	AR22PCR-7@@@#	-	-	
AH22-PCL3#@*%&	-	-	-	
AH22-PCL4#@*%&	-	-	-	
AH22-PCL5#@*%&	-	-	-	
AH22/25-PL0#@*%&	AR22PL-0@@*%&#	AH30-PL0#@*%&	AR30PL-0@@*%&#	
AH22-PL1#@*%&	-	AH30-PL1#@*%&	-	
AH22/25-PL2#@*%&	AR22PL-2@@*%&#	AH30-PL2#@*%&	AR30PL-2@@*%&#	
AH22-PL3#@*%&	AR22PL-3@@*%&#	AH30-PL3#@*%&	AR30PL-3@@*%&#	
AH22-PL6#@*%&	AR22PL-6@@*%&#	AH30-PL6#@*%&	AR30PL-6@@*%&#	
AH22-PL7#@*%&	AR22PL-7@@*%&#	AH30-PL7#@*%&	AR30PL-7@@*%&#	

@: contacts arrangement  
#: color of button or grove  
\*: lamp voltage

&: lamp type  
\$: draw-out position of key  
%: type of key

PART #	PART #	PART #	PART #	TYPE
AH22-PR0#@@	AR22RR-0@@#	-	-	Selector switch
AH22-PR1#@@	AR22RR-1@@#	-	-	
AH22-PR2#@@	AR22RR-2@@#	-	-	
AH22-PR3#@@	AR22RR-3@@#	-	-	
AH22-PR6#@@	AR22RR-6@@#	-	-	
AH22-PR7#@@	AR22RR-7@@#	-	-	
AH22-PRC1#@@@	AR22RCR-1@@@#	-	-	
AH22-PRC3#@@@	AR22RCR-3@@@#	-	-	
AH22-PRC4#@@@	AR22RCR-4@@@#	-	-	
AH22-PRC5#@@@	AR22RCR-5@@@#	-	-	
AH22-PRC6#@@@	AR22RCR-6@@@#	-	-	
AH22-PRC7#@@@	AR22RCR-7@@@#	-	-	
AH22/25-PW0#@@	AR22WR-0@@#	AH30-PW0#@@	AR30WR-0@@#	
AH22/25-PW1#@@	AR22WR-1@@#	AH30-PW1#@@	AR30WR-1@@#	
AH22/25-PW2#@@	AR22WR-2@@#	AH30-PW2#@@	AR30WR-2@@#	
AH22/25-PW3#@@	AR22WR-3@@#	AH30-PW3#@@	AR30WR-3@@#	
AH25-PW5#@@	AR22WR-6@@#	-	-	
AH22-PW6#@@	AR22WR-6@@#	AH30-PW5#@@	AR30WR-6@@#	
AH22-PW7#@@	AR22WR-7@@#	-	AR30WR-7@@#	
AH22-PWC1#@@@	AR22WCR-1@@@#	-	-	
AH22-PWC3#@@@	AR22WCR-3@@@#	-	-	
AH22-PWC4#@@@	AR22WCR-4@@@#	-	-	
AH22-PWC5#@@@	AR22WCR-5@@@#	-	-	
AH22-PWC6#@@@	AR22WCR-6@@@#	-	-	
AH22-PWC7#@@@	AR22WCR-7@@@#	-	-	
-	-	AH30-Q#11	-	Push-pull
AH22-Q2#@@	AR22Q2R-@@#	AH30-Q2#@@	AR30Q2R-@@#	
AH22-S1C4#*(-N)	DR22N1-(N)*#	AH30-S1C4#*(-N)	DR30N1-(N)*#	Numerical indicator
AH22-S2C4#*(-N)	DR22N2-(N)*#	AH30-S2C4#*(-N)	DR30N2-(N)*#	
AH22/25-S1#@@	AR22S1R-22#	AH30-S1#@@	AR30S1R-22#	w/selector ring
AH22/25-S2#@@	AR22S2R-@@#	AH30-S2#@@	AR30S2R-@@#	
AH22/25-S3#@@	AR22S3R-@@#	AH30-S3#@@	AR30S3R-@@#	
AH22/25-S4#@@	-	AH30-S4#@@	-	
AH22/25-S5#@@	-	AH30-S5#@@	-	
AH22/25-S6#@@	AR22S6R-@@#	AH30-S6#@@	AR30S6R-@@#	
AH22/25-SE#@@	AR22E0S-@@#	AH30-SE#@@	(AR22 series+AR9Y003)	Extended head
AH22/25-SE5#@@	AR22E5S-@@#	AH30-SE5#@@	(AR22 series+AR9Y003)	
AH22-SEL#@@*&	AR22E0M-@@*&#	-	-	
AH22-SEL5#@@*&	AR22E5M-@@*&#	-	-	
AH22/25-SF#@@	AR22F0S-@@#	AH30-SF#@@	(AR22 series+AR9Y003)	Flush head
AH22/25-SF5#@@	AR22F5S-@@#	AH30-SF5#@@	(AR22 series+AR9Y003)	
AH22-SFL#@@*&	AR22F0M-@@*&#	-	-	
AH22-SFL5#@@*&	AR22F5M-@@*&#	-	-	
AH25-SJ2#@@	AR22JY-2\$@@%	AH30-SJ2#@@	(AR22 series+AR9Y003)	Selector switch
AH25-SJ3#@@	AR22JY-3\$@@%	AH30-SJ3#@@	(AR22 series+AR9Y003)	
AH25-SL#@@*&	AR22E0M-@@*&#	AH30-SL#@@*&	(AR22 series+AR9Y003)	Extended
AH25-SL1#@@*&	AR22F0M-@@*&#	AH30-SL1#@@*&	(AR22 series+AR9Y003)	Flush
AH25-SL5#@@*&	AR22E5M-@@*&#	AH30-SL5#@@*&	(AR22 series+AR9Y003)	Extended
AH25-SL6#@@*&	AR22F5M-@@*&#	AH30-SL6#@@*&	(AR22 series+AR9Y003)	Flush
AH25-SP2#@@	AR22PY-2@@#	AH30-SP2#@@	(AR22 series+AR9Y003)	Selector switch
AH25-SP3#@@	AR22PY-3@@#	AH30-SP3#@@	(AR22 series+AR9Y003)	

@: contacts arrangement  
#: color of button or grove  
\*: lamp voltage

&: lamp type  
\$: draw-out position of key  
%: type of key

PART #	PART #	PART #	PART #	TYPE
AH22-SZ#*&	DR22F3M-*&#	AH30-SZ#*&		Pilot light
AH22-TZ#*&	DR22E3N-*&#	-	-	
-	-	AH30-T#11*&	AR30Q7L-11*&#	Push-pull
AH22-UH@@	-	-	-	Wabble
AH25-UB@@	-	AH30-UB@@	-	stick
-	-	AH30-V1R@@	AR30V1R-@@R	E-stop
-	-	AH30-V5R@@	-	
-	-	AH30-V6R@@	-	
-	-	AH30-VEL1R@@	-	
-	-	AH30-VELR@@*&	AR30V2L-@@*&R	
-	-	AH30-VER@@	AR30V2R-@@R	
AH22-VJR@@	AR22V7R-@@R	-	-	
AH22-VL1R@@*&	AR22VAL-@@*&R	-	-	
AH22/25-VLR@@*&	AR22V2L-@@*&R	AH30VLR@@*&	AR30V2L-@@*&R	
AH22-VNLR@@*&	AR22VKL-@@*&R	-	-	
AH22-VNR@@	AR22VKR-@@R	-	-	
AH22/25-VR@@	AR22V2R-@@R	AH30-VR@@*	AR30V2R-@@R	
AH22-VSJR@@	AR22V7R-@@R	-	-	
AH22-VSLR@@*&	AR22V2L-@@*&R	-	-	
AH22-VSR@@	AR22V4R-@@R	-	-	
-	-	AH30-W1#@@	-	Lever
-	-	AH30-W3#@@	-	select
-	-	AH30-X1B*	DR30B6-*B	Buzzer
AH22-X2B*	DR22B3-*B	AH30-X2B*	DR30B0-*B	
AH22-XB*	DR22B5-*B	AH30-XB*	DR30B5-*B	
AH22-YE#@@	AR22E0Y-@@#	-	-	Extended
AH22-YE5#@@	AR22E5Y-@@#	-	-	head
AH22-YEL#@*&	AR22E0P-@@*&#	-	-	
AH22-YEL5#@*&	AR22E5P-@@*&#	-	-	
AH22-YF#@@	AR22F0Y-@@#	-	-	Flush
AH22-YF5#@@	AR22F5Y-@@#	-	-	head
AH22-YJ0A@@%	AR22JY-0A@@%	-	-	Selector
AH22-YJ1E@@%	AR22JY-1E@@%	-	-	switch
AH22-YJ2\$@@%	AR22JY-2\$@@%	-	-	
AH22-YJ3\$@@%	AR22JY-3\$@@%	-	-	
AH22-YJ6\$@@%	AR22JY-6\$@@%	-	-	
AH22-YJ7\$@@%	AR22JY-7\$@@%	-	-	
AH22-YJC1E@@@%	AR22JCY-1\$@@@%	-	-	
AH22-YJC3\$@@@%	AR22JCY-3\$@@@%	-	-	
AH22-YJC6\$@@@%	AR22JCY-6\$@@@%	-	-	
AH22-YJC7\$@@@%	AR22JCY-7\$@@@%	-	-	
AH22-YMS#@@	AR22M4Y-@@#	-	-	Mushroom
AH22-YMS5#@@	-	-	-	head

@: contacts arrangement  
#: color of button or grove  
\*: lamp voltage

&: lamp type  
\$: draw-out position of key  
%: type of key

PART #	PART #	PART #	PART #	TYPE
AH22-YP0#@@	AR22PY-0@@#	-	-	Selector switch
AH22-YP1#@@	AR22PY-1@@#	-	-	
AH22-YP2#@@	AR22PY-2@@#	-	-	
AH22-YP3#@@	AR22PY-3@@#	-	-	
AH22-YP6#@@	AR22PY-6@@#	-	-	
AH22-YP7#@@	AR22PY-7@@#	-	-	
AH22-YPC1#@@@	AR22PCY-1@@@#	-	-	
AH22-YPC3#@@@	AR22PCY-3@@@#	-	-	
AH22-YPC6#@@@	AR22PCY-6@@@#	-	-	
AH22-YPC7#@@@	AR22PCY-7@@@#	-	-	
AH22-YPL0#@@*&	AR22PP-0@@*&#	-	-	
AH22-YPL1#@@*&	AR22PP-1@@*&#	-	-	
AH22-YPL2#@@*&	AR22PP-2@@*&#	-	-	
AH22-YPL3#@@*&	AR22PP-3@@*&#	-	-	
AH22-YPL6#@@*&	AR22PP-6@@*&#	-	-	
AH22-YPL7#@@*&	AR22PP-7@@*&#	-	-	
AH22-YPR0#@@	AR22RY-0@@#	-	-	
AH22-YPR1#@@	AR22RY-1@@#	-	-	
AH22-YPR2#@@	AR22RY-2@@#	-	-	
AH22-YPR3#@@	AR22RY-3@@#	-	-	
AH22-YPR6#@@	AR22RY-6@@#	-	-	
AH22-YPR7#@@	AR22RY-7@@#	-	-	
AH22-YPRC1#@@@	AR22RCY-1@@@#	-	-	
AH22-YPRC3#@@@	AR22RCY-3@@@#	-	-	
AH22-YPRC6#@@@	AR22RCY-6@@@#	-	-	
AH22-YPRC7#@@@	AR22RCY-7@@@#	-	-	
AH22-YPW0#@@	AR22WY-0@@#	-	-	
AH22-YPW1#@@	AR22WY-1@@#	-	-	
AH22-YPW2#@@	AR22WY-2@@#	-	-	
AH22-YPW3#@@	AR22WY-3@@#	-	-	
AH22-YPW6#@@	AR22WY-6@@#	-	-	
AH22-YPW7#@@	AR22WY-7@@#	-	-	
AH22-YPWC1#@@@	AR22WCY-1@@@#	-	-	
AH22-YPWC3#@@@	AR22WCY-3@@@#	-	-	
AH22-YPWC6#@@@	AR22WCY-6@@@#	-	-	
AH22-YPWC7#@@@	AR22WCY-7@@@#	-	-	
AH22-YS1 to 6#*&	-	-	-	w/selector ring
AH22-YZ#*&	DR22E3P-*&#	-	-	Pilot light
AH22-Z#*&	DR22E3L-*&#	-	-	
AH22/25-ZM#*&	DR22D0L-*&#	AH30-ZM#*&	DR30D0L-*&#	
AH25-ZN#*&		AH30-ZN#*&	DR30F4M-*&#	
-	DR22F4M-*&#	-	-	
-	-	AH30-ZN1#*&	DR30F4N-*&#	
-	-	AH30-ZN2#*&	DR30F4N-*&#	
-	-	AH30-ZN4#*&	DR30M4M-*&#	
AH25-ZK#*&	DR22K0L-*&#	AH30-ZK#*&	DR30K0L-*&#	
AH25-ZS#*&	DR22E3M-*&#	-	-	
-	-	AH30-ZS#*&	DR30F4M-*&#	
-	-	AH30-ZV#*&	DR30D1L-*&#	

@: contacts arrangement  
#: color of button or grove  
\*: lamp voltage

&: lamp type  
\$: draw-out position of key  
%: type of key

## AH-series cross to AR-series (Control type selector switch)

AH22	AH25 (*1)	AR22	AH30 (*1)	AR30
AH22-%#012	AH25-PC#012	AR22&-3014#	AH30-\$#012	AR30&-3014#
AH22-%#022	AH25-PC#022	AR22&-3024#	AH30-\$#022	AR30&-3024#
AH22-%#032	AH25-PC#032	AR22&-303C#	AH30-\$#032	AR30&-303C#
AH22-%#033 (*1)	-	AR22&-303C#	-	-
AH22-%#042	AH25-PC#042	AR22&-3044#	AH30-\$#042	AR30&-3044#
AH22-%#052	AH25-PC#052	AR22&-3054#	AH30-\$#052	AR30&-3054#
AH22-%#062	AH25-PC#062	AR22&-3064#	AH30-\$#062	AR30&-3064#
AH22-%#071	-	AR22&-307F#	-	-
AH22-%#072	AH25-PC#072	AR22&-307C#	AH30-\$#072	AR30&-307C#
AH22-%#073 (*1)	-	AR22&-307C#	-	-
AH22-%#082	AH25-PC#082	AR22&-3084#	AH30-\$#082	AR30&-3084#
AH22-%#092	AH25-PC#092	AR22&-3094#	AH30-\$#092	AR30&-3094#
AH22-%#102	AH25-PC#102	AR22&-3104#	AH30-\$#102	AR30&-3104#
AH22-%#112	AH25-PC#112	AR22&-311C#	AH30-\$#112	AR30&-311C#
AH22-%#114 (*1)	-	AR22&-311C#	-	-
AH22-%#122	AH25-PC#122	AR22&-3124#	AH30-\$#122	AR30&-3124#
AH22-%#132	AH25-PC#132	AR22&-3134#	AH30-\$#132	AR30&-3134#
-	AH25-PC#142	AR22&-314D#	AH30-\$#142	AR30&-314D#
AH22-%#143	-	AR22&-314D#	-	-
-	AH25-PC#152	AR22&-315A#	AH30-\$#152	AR30&-315A#
AH22-%#153	-	AR22&-315A#	-	-
AH22-%#162	AH25-PC#162	AR22&-3164#	AH30-\$#162	AR30&-3164#
AH22-%#172	AH25-PC#172	AR22&-3174#	AH30-\$#172	AR30&-3174#
AH22-%#182	AH25-PC#182	AR22&-3184#	AH30-\$#182	AR30&-3184#
AH22-%#192	AH25-PC#192	AR22&-3194#	AH30-\$#192	AR30&-3194#
-	AH25-PC#202	AR22&-320B#	AH30-\$#202	AR30&-320B#
AH22-%#204	-	AR22&-320B#	-	-
-	AH25-PC#212	AR22&-3094#	AH30-\$#212	AR30&-3094#
AH22-%#412	-	AR22&-441C#	-	-
AH22-%#512	-	AR22&-551C#	-	-

%: JC, PC, PRC, PWC, YPC, YPRC, YPW, YJC, PCL

\$: PC, JC

&: JCR, PCR, RCR, WCR, JCY, PCY, RCY, WCY

Note \*1: Terminal wirings for AR series are different from AH series

Knob	Bezel	AH22	AH25 (*1)	AR22	AH30 (*1)	AR30
Standard	Round	PC	PC	PCR	PC	PCR
	Square	YPC	-	PCY	-	-
Long	Round	PWC	-	WCR	-	-
	Square	YPWC	-	WCY	-	-
Round	Round	PRC	-	RCR	-	-
	Square	YPRC	-	RCY	-	-
Key	Round	JC	-	JCR	JC	JCR
	Square	YJC	-	JCY	-	-
Illuminated Standard	Round	PCL	-	-	-	-

## RCa470-series Pushbutton cross to AR-series Pushbutton

PART #	PART #	TYPE	
RCa470-AE#@	AR30E5R-@@#	Round extended head	
RCa470-AF@	AR30F5R-@@#	Flush head	
RCa470-AG#@	-	w/guard	
RCa470-AG1#@	AR30G6R-@@#	w/guard	
RCa470-B1#@	AR30B0R-@@#	Giant head	
RCa470-B2#@	AR30B1R-@@#		
RCa470-B3#@	AR30B2R-@@#		
RCa470-B4#@	AR30B3R-@@#		
RCa470-D@%	-		Push button w/key
RCa470-EF#@	AR30E0R-@@#	Round extended head	
RCa470-F#@	AR30F0R-@@#	Flush head	
RCa470-G#@	AR30G0R-@@#	w/guard	
RCa470-G1#@	AR30G1R-@@#		
RCa470-H2#@	AR30WR-2@@#	Selector switch	
RCa470-H3#@	AR30WR-3@@#		
RCa470-HA01#@	AR30WR-1@@#		
RCa470-J2\$@%	AR30JR-2\$@@%	Key selector switch	
RCa470-J3\$@%	AR30JR-3\$@@%		
RCa470-JA01\$@%	AR30JR-1E@@%		
RCa470-JA2\$@%	AR30JR-0A@@%		
RCa470-JA3\$@%	AR30JR-6\$@@%		
RCa470-JC3\$@@@%	AR30JCR-3\$@@@%		
RCa470-K2\$@%	-		
RCa470-K3\$@%	-		
RCa470-L#@(T)*	AR30E0L-@*#&#		Round extended head
RCa470-L#@(T)*G	AR30G4L-@*#&#		w/guard
RCa470-L#@*GS	AR30G3L-@*#&#		
RCa470-L3#@(T)*	-	Round extended head	
RCa470-L4#1(T)*	-		
RCa470-M#@	AR30M0R-@@#	Mushroom head	
RCa470-M1#@	-		
RCa470-M2#@	AR30M3R-@@#		
RCa470-N#@	AR30N0R-@@R		Turn-lock

PART #	PART #	TYPE
RCa470-P2#@	AR30PR-2@@#	Selector switch
RCa470-P3#@	AR30PR-3@@#	
RCa470-PA01#@	AR30PR-1@@#	
RCa470-PA2#@	AR30PR-0@@#	
RCa470-PA3#@	AR30PR-6@@#	
RCa470-PC#@@@	AR30PCR-3@@@#	
RCa470-PL3#2@*	AR30PL-2@*#&#	
RCa470-PL3#3@*	AR30PL-3@*#&#	
RCa470-Q#@	-	Pull type
RCa470-S1#2	AR30S1R-22#	w/selector ring
RCa470-S2#2	AR30S2R-22#	
RCa470-S3#2	AR30S3R-22#	
RCa470-S4#2	-	
RCa470-S5#2	-	
RCa470-S6#2	AR30S6R-22#	
RCa470-T#1(T)*	AR30Q7L-11*#&#	Push-pull
RCa470-UB@	AR30A!!-@@@B	Wabble stick type
RCa470-V#@	AR30V0R-@@#	E-stop
RCa470-V1#@	AR30V1R-@@R	
RCa470-V1J#@	-	
RCa470-VJ#@	-	
RCa470-W1#@	-	Lever select
RCa470-W3#@	-	
RCa470-ZK#(T)*	DR30K0L-*#&#	Pilot light
RCa470-ZK3#(T)*	-	
RCa470-ZM#(T)*	DR30D0L-*#&#	
RCa470-ZM3#(T)*	-	
RCa470-ZN#(T)*	DR30F4M-*#&#	
RCa470-ZN1#(T)*	DR30F4N-*#&#	
RCa470-ZN2#(T)*	-	
RCa470-ZN3#(T)*	-	
RCa470-ZS#(T)*	-	
RCa470-ZS3#(T)*	-	

@: contacts arrangement

#: color of button or grove

\*: lamp voltage

&: lamp type

\$: draw-out position of key

#: type of key