



# FRENIC 5000G11S/P11S

## High-Performance, Low-Noise Inverter

General-Purpose Industrial Machines

230V Series

0.25HP/FRNF25G11S-2UX  
to 125HP/FRN125G11S-2UX

460V Series

0.50HP/FRNF50G11S-4UX  
to 600HP/FRN600G11S-4UX

Fans and Pumps

230V Series

7.5HP/FRN007P11S-2UX  
to 150HP/FRN150P11S-2UX

460V Series

7.5HP/FRN007P11S-4UX  
to 800HP/FRN800P11S-4UX



## CAUTION

- Read all operating instructions before installing, connecting (wiring), operating, servicing, or inspecting the inverter.
- Ensure that this instruction manual is made available to the final user of the inverter.
- Store this manual in a safe, convenient location.
- The product is subject to change without prior notice.

